


HPE ProLiant Gen10 Servers - Base System Device Driver Missing Under Device Manager in Microsoft Windows Operating System

Table of contents

- Issue
- Environment
- Cause
- Resolution

Issue

- Yellow exclamation mark observed in Device Manager for various devices under other devices section.
- This is usually observed after Manual OS Installation of Microsoft Windows Server Edition.
- Common Device Drivers missing are -
- Base System Device Driver
- PCI Device
- Chipset Root Port Driver
- PCI Memory Controller
- USB Controller
- PCI Encryption/Decryption Controller



Environment

- HPE ProLiant Gen10 Servers
- Microsoft Windows Server 2012 R2
- Microsoft Windows Server 2016
- Microsoft Windows Server 2019

Cause

• Chipset Driver or iLO Drivers missing or corrupt.

Resolution

Install Chipset Identifier Driver, ILO Channel Interface Driver (CHIF) and ILO Automatic Server recovery Driver (ASR)

NOTE-

Depending upon the Processor Model, The Chipset Driver would be applied.

Intel® Xeon® E Processor and Xeon® Scalable (First and Second Generation) are two different processors and have separate chipset drivers.

For AMD EPYC Processors, Install "Identifiers for AMD EPYC Processors for Windows"

For Base System Device - ILO 5 CHIF and ASR Drivers are the Base System Device and updating the drive would resolve the issue.

How and What to download?

- 1. Click here to access the drivers and download link.
- 2. Enter a product name (e.g., DL380 Gen 10) and click on Search.
- 3. Select the specific ProLiant model.
- 4. Select the appropriate operating system (e.g., Windows 2012 R2 or Windows 2016).
- 5. Click on the category Driver System Management.
- 6. Download the following files and install them.

CHIPSET DRIVER FOR INTEL PROCESSOR (Depending upon the Processor Model)

• Identifiers for Intel Xeon Scalable Processors (First and Second Generation) for Windows

OR

• Identifiers for Intel Xeon E-21xx Processor for Windows Server 2016 and Server 2019

CHIPSET DRIVER FOR AMD EPYC PROCESSOR-

• Identifiers for AMD EPYC Processors for Windows

BASE SYSTEM DEVICE DRIVER

- iLO 5 Channel Interface Driver for Windows Server 2016 and Server 2019
- iLO 5 Automatic Server Recovery Driver for Windows Server 2016 and Server 2019

Note: Server reboot may be required to complete the driver installation.

Contact Author - Shabaz Ahmed Dar for any doubts/Clarification